


Low Capacitance CSA/ATEX Intrinsic Safety Control Drawing & Overview

Delta-3N Kft. 7030 Paks, Jedlik Á. u. 2 Tel.: +36 75 510 115 Fax: +36 75 510 114 drnagyi@delta3n.hu www.delta3n.hu

For AC91X Series

Intrinsic Safety Control Drawing



Overview & Requirements

 A barrier is required for the installation of IS sensors. The barrier passes signals in either direction as required but limits the voltage and current that can reach the hazardous area under fault conditions. The barrier is put in series and is installed in a safe area (see Typical Connection Diagram).

Proper IS Barrier must be used with this sensor to ensure compliance with entity parameters


- IS111 and IS211 barriers are compatible with AC91X series sensors
- Please contact a CTC Representative if you require assistance in specifying the correct barrier for CTC sensors
 Approved cabling (maximum 1640 ft./500 m) of CB102, CB103, CB193, CB111, or CB206 must be used to bring the signal from the sensor to the Zener diode barrier or galvanic isolator, which is the energy-limiting interface. The standard cable, for integral cables is CB103 polyurethane jacketed, twisted, shielded pair cable
- Sensors must be grounded to a grounded structure by stud mounting the sensor directly to the machine surface, ensuring metal (of the sensor) to metal (of the machine surface) contact

Entity Parameters

All CTC Sensors have the identical entity parameters for their IS approved sensors. This information is used to specify the barrier required for the installation of the IS sensors.

Model	Description	Vmax	Ci	Imax	Li	Pi	Vmax = Maximum Voltage	
AC91X Series	Accelerometer	28 V	0 nF	100 mA	0 uH	1 W	Ci = Total Capacitance of Circuit Allowable	
LP812 Series	Loop Powered 4-20 mA output sensor, velocity	28 V	0 nF	100 mA	0 uH	1 W	Imax = Maximum Allowable Current	
LP912 Series	Loop Powered 4-20 mA	28 V	0 nF	100 mA	0 uH	1 W	Li = Total Inductance of Circuit Allowable	
	output sensor, acceleration						Pi = Total Power of Circuit Allowable	

Regulatory Approvals





Backed by our Unconditional Lifetime Warranty Page 81 • 800-999-5290